



Порт BIOS #FC37: Упр. ОЗУ, порт ПЗУ
 Порт BIOS #FD37: Управление теем ОЗУ
 Порт BIOS #FE37: Упр. ПЗУ, блок памяти
 Порт BIOS #FE37: Расширение видеоконтроля



Конт. №	Конт. №	Конт. №	Конт. №	Конт. №
881	882	883	884	885
886	887	888	889	890
891	892	893	894	895
896	897	898	899	900
901	902	903	904	905
906	907	908	909	910
911	912	913	914	915
916	917	918	919	920
921	922	923	924	925
926	927	928	929	930
931	932	933	934	935
936	937	938	939	940
941	942	943	944	945
946	947	948	949	950
951	952	953	954	955
956	957	958	959	960
961	962	963	964	965
966	967	968	969	970
971	972	973	974	975
976	977	978	979	980
981	982	983	984	985
986	987	988	989	990
991	992	993	994	995
996	997	998	999	1000

